## OCONEE COUNTY PROCUREMENT OFFICE 415 S. PINE STREET, ROOM 100 WALHALLA, SC 29691

Robyn M. Courtright, CPPO, Procurement Director

Tronda Spearman, CPPB, Assistant Procurement Director

Telephone: Fax: 864-638-4141 864-638-4142

### ADDENDUM NO. 2 ITB 17-03

# DRILLING SERVICES FOR SENECA LANDFILL – GROUNDWATER REMEDIATION PILOT STUDY

#### OPENING DATE: NOVEMBER 2, 2017 AT 2:00 PM - UNCHANGED

Please include a copy of this Addendum No. 2, signed with your bid.

#### Below is the answer to Question 15 from Addendum 1:

**Question 15:** What type of tooling is needed for boring injections? **Answer 15:** We have received the following clarification from Regenesis:

Regenesis will provide a retractable screen tool that will be placed on the end of the tooling string. The retractable screen is the item which our remediation products exit from, into the subsurface. We use the tooling as it is designed to maximize the horizontal distribution, giving the best opportunity for the remediation products to enter the designed subsurface injection interval. Each of these tools are 4 ft long, they are threaded with 1.5 inch Geoprobe (rope) threads. The drilling subcontractor would be bringing the equipment and items specific to the drilling and hole abandonment tasks. We would ask them to bring enough 1.5 inch Geoprobe tooling to inject on 4 locations simultaneously. I have included an equipment list below.

- Track mounted Geoprobe with operator-model no. 6620 of 7822
- 160 feet of 1.5 inch injection rods (geoprobe thread)
- Traffic cones
- Granular bentonite and bentonite chips (approximately 15 bags of each)
- Detachable skinny rods to run down the rod string in the event of clogging
- Teflon tape for rod threads
- 2 expendable tip holders
- 30 expendable tips

#### Clarification:

During the pre-bid meeting it was stated that Contractors would need to drum all IDW and stage it on pallets but would not be responsible for disposal. Please clarify Question 11 from Addendum 1 that states the following:

Question 11: Is disposal of de-con waters required?

**Answer 11:** Yes, this will be the responsibility of the Contractor.

**Final Answer:** The decontamination water should be drummed and staged by the Contractor with the other investigative derived waste (IDW). The County will handle disposal of the drums.

## END ADDENDUM NO. 2

Please acknowledge receipt of Addendum by s BY:	DATE:
(Contractor)	
(Signature)	(Title of Signing Officer)